

Bild



Skruvsats

- 4st. Insex screw M8x50
- 4st. Locknut M8
- 4st. Insex screw M6x8
- 1st. Allen key 5mm
- 1st. Allen key 6mm
- 1st. Sheet metal key



Screw the handlebar to the chassis with an M8x50 Allen screw.



Screw the wire baskets in place with Allen screws M6x8. Place the toolflex with the tube attachment and screw.



