

Monteringsbeskrivning



Fäll upp trådbyglarna och trä in säcken underifrån mellan trådbyglarna.



Vik säcken över den ena trådbygel.



Gör sedan likadant på motsvarande sida och fäll ner trådbyglarna.



Fixera säcken genom att dra den neråt enligt bilden.

29071 Cleaningtrolley Puhastus Small

Skruvsats

1 st. Platekey 10/13

1 st. Allen Key 6 mm

1 st. Allen Key 5 mm

4 st. Allen Screw M8x50 mm


4 st. Lock Nut M8

2 st. Allen Screw M6x8 mm

2 st. Allen Screw M6x12 mm

Monteringsbeskrivning

29071 Cleaningrolley Puhastus Small



Mount the handlebar to the bottom frame with Allen Screw M8x50mm and the M8 lock nut
(Marking)

- 1:** Place the Mop frame holder and push then down on the bottom frame. **(Marking 1)**
- 2:** Place the Wire basket XL on the handlebar. **(Marking 2)**

Monteringsbeskrivning

29071 Cleaningtrolley Puhastus Small



1: Place the Sack Holder 125L on the handlebar threaded holes and fasten it with M6x12 (**Marking 1**)

2: Place Basket Large on the handlebar and fasten it with M6x8 (**Marking 2**)

Place all the other details accordingly as shown in the picture.

A complete 2971 Cleaningtrolley Puhastus Small.